

**Note:** Dimensions are nominal measurements only

## SPECIFICATIONS

RECOMMENDED USE	Domestic
MATERIAL	304 Stainless Steel
INSTALLATION	Undercounter - Top or Under Mount
OVERFLOW	No
CAPACITY	9.45L
RIM THICKNESS	27mm


Disclaimer: Products in this manual must by law be installed by licensed and registered tradespeople in accordance with the relevant standards. ABI and the manufacturer/distributor reserve the right to vary specifications or delete models from their range without prior notification. Dimensions are nominal measurements only. The information listed is correct at the time of publication, however ABI and the manufacturer/distributor takes no responsibility for printing errors. Copyright © ABI Interiors 2021

## INSTALLATION GUIDE - TOP MOUNT

Note: This product must be installed by a licensed plumber. This is a general installation guide - there are many factors that are involved that can alter the installation method. This product install must comply with AS/NZS 3500.


- 1 Mark out desired location of sink using the cut out template dimensions provided.

Cut out basin hole using preferred method.  
**Note:** If cutting a stone benchtop it will need to be cut in a controlled environment by a licensed tradesperson as per OH&S regulations.



- 2 Clean around the edge of benchtop basin hole & perimeter of basin rim.

Apply silicon to the underside perimeter of basin rim & lower into position.




Regularly clean with mild liquid detergent or soap and water




DO NOT use cream cleaners or bleach. These substances are abrasive



DO NOT use cleaning pads with abrasive surfaces as this may scratch the material



- 3 Wipe away any excess silicon around basin rim.



# INSTALLATION GUIDE - UNDER MOUNT


Note: This product must be installed by a licensed plumber.  
This is a general installation guide - there are many factors that are involved that can alter the installation method. This product install must comply with AS/NZS 3500.



- 1 Mark out desired location of basin using the cut out template dimensions provided.


Cut out basin hole using preferred method.

**Note:** If cutting a stone benchtop it will need to be cut in a controlled environment by a licensed tradesperson as per OH&S regulations.



- 2 Clean around the edge of benchtop basin hole & perimeter of basin rim.


Position the basin in the cabinet below the benchtop hole. Apply silicon to the perimeter of basin rim & lift into position.



- 3 Lay a piece of timber across the benchtop hole & position in line with basin hole below.

Place clamp through the sink hole & tighten the clamp to hold the basin in place. Wipe away any excess silicon around benchtop opening.

Note: Use rags to protect surfaces when either the clamp or timber is making contact with the benchtop or basin.




- 4 Using the benchtop material build rebated mounting tabs.

Clean around the underside perimeter of the basin & the mounting tabs.

Apply silicon to the mounting tab & fix it to the underside of the benchtop & basin rim. Repeat tabs at regular intervals.

Wipe away any excess silicon around mounting tabs.



Regularly clean with mild liquid detergent or soap and water



DO NOT use cream cleaners or bleach. These substances are abrasive



DO NOT use cleaning pads with abrasive surfaces as this may scratch the material

