


SAMA CABINETRY KNOB



Note: Dimensions are nominal measurements only

SPECIFICATIONS	
RECOMMENDED USE	Domestic
CONSTRUCTION	Solid Brass
MOUNTING HARDWARE INCLUDED	Yes
SCREW / BOLT TYPE	M4*25mm
MOUNTS FROM	Front
HOLE DISTANCE	N/A

Disclaimer: Products in this specification manual must by regulation be installed by licensed and registered trade people. The manufacturer/distributor reserves the right to vary specifications or delet models from their range without prior notification. Dimensions are nominal measurements only. Dimensions and set-outs listed are correct at time of publication however the manufacturer/distributor takes no responsibility for printing errors. All ABI Products are designed in Australia. Copyright ABI Interiors Pty Ltd 2021.

INSTALLATION GUIDE

Note: This product must be installed by a licensed tradesperson.


This is a general installation guide - there are many factors that are involved that can alter the installation method.

This product install must comply with the standards in your

respective country and must be adhered to by your licensed tradesperson.

- 1 Determine the position of the cabinetry pull.
- Use the tape measure to find the centre of the cabinetry panel (if you are installing only a single pull). Or divide your cabinetry panel into quarters, or a placement you prefer (if you are installing two pulls on the cabinetry panel).
- $\overline{3}$ Use the pencil to mark the centre of the holes.
- 4 Drill out the centre of marked holes with a smaller drill bit first (e.g. 2.5mm).
- Use the level to make sure that the holes are aligned. Adjust the markings, if needed. Drill correct size hole of 4mm.
- 6 Mount the pull to the cabinetry and use the screwdriver to tighten the bolt.

REQUIRED TOOLS AND MATERIALS





Regularly clean with mild liquid detergent or soap and water.



DO NOT use cream cleaners or bleach.
These substances are abrasive.



DO NOT use cleaning pads with abrasive surfaces as this may scratch the material.